

INDUCTORS							
* = original equipment	S90 058927	S70 061569	S180 059269	S20/B1 (20°) 064874	S180/B1 064881	S180/B2 064928	S180/B3W 067899
37 LG	✓*			✓		—	✓
39 & 50 LG				✓ with adapter 28S			
110, 160 & 220 LG				✓ with adapter 32S			

NEW			
Ø 20	S20/D20 078796	S90/D20 078871	S180/D20 069985
Ø 25	S20/D25 078802	S90/D25 078888	S180/D25 069992
Ø 30	S20/D30 078819	S90/D30 078895	S180/D30 070592
Ø 35	S20/D35 078826	S90/D35 078901	S180/D35 070608
Ø 40	S20/D40 078833	S90/D40 078918	S180/D40 070615
Ø 45	S20/D45 078840	S90/D45 078925	S180/D45 070622
Ø 50	S20/D50 078857	S90/D50 078932	S180/D50 070639
Ø 55	S20/D55 078864	S90/D55 078949	S180/D55 070646
37 LG	✓ S20/D20-D35, S90/D20-D35, S180/D20-D35		
39 & 50 LG	✓ with adapter 28S		
110, 160 & 220 LG	✓ with adapter 32S		
Protection kit for L180/D inductors - Kit de protection pour inducteurs boucle 077386 			

NEW			
	S180 HEAT TUBE D37 078604	S180 HEAT TUBE D40 078611	S180 HEAT TUBE D50 078628
37 LG	—		
39 & 50 LG	✓ with adapter 28S		
110, 160 & 220 LG	✓ with adapter 32S		
DIFFICULT ACCESS ADAPTERS			
		✓ compatible with 180/B1 ✓ compatible with 180/B2 ✓ compatible with 180/B3W	
	90°-S 082663		
ADAPTERS			
	28S M28 Ø16 064485		
	32S M32 Ø16 064508		
37 LG	—		
39 & 50 LG	✓ 28S M28 Ø16		
110, 160 & 220 LG	✓ 32S M32 Ø16		

Boxes		
 28S/B type W for 39LG & 50LG 072497 included: S20/B1 (x1) S180/B1 (x1) S180/B3 (x1) 28S (x1) B1 (x1) B3 (x1)	 32S/B type W for 110LG & 160LG 072503 included: S20/B1 (x1) S180/B1 (x1) S180/B3 (x1) 32S (x1) B1 (x1) B3 (x1)	 L box 065796 included: L180 (x1)

Trolley for inductor for adapter 32L
Chariot pour inducteurs pour adaptateur 32L 075955 4 to 8 wheels

Ferrites										
 B1 053823	 B1 (x5) 079380	 B2 053458	 B3 067875	 B4 053755	 B5 079489	 B1 (x5) 079397	 B2 056916	 B3 072527	 B4 054844	 Spiral 069701

Glue kit for inductor
Kit de colle pour inducteur 075948

INDUCTORS							
* = original equipment	L90 (90°) 059788	L70 (70°) 059771	L180 059795	L180/Spiral 065000	L20/B4 067882	L20 Alu Glove 069114	L180/B4 079786
37 LG				—			
39 & 50 LG				✓ with adapter 28L			
110, 160 & 220 LG	✓ with adapter 32L*			✓ with adapter 32L	✓ with adapter 32L*	✓ with adapter 32L	✓ with adapter 32L

NEW			
Ø 60	L20/D60 078956	L90/D60 079106	L180/D60 069923
Ø 70	L20/D70 078963	L90/D70 079113	L180/D70 069930
Ø 80	L20/D80 078970	L90/D80 079120	L180/D80 069121
Ø 90	L20/D90 078987	L90/D90 079137	L180/D90 069947
Ø 100	L20/D100 078994	L90/D100 079144	L180/D100 069954
Ø 110	L20/D110 079007	L90/D110 079151	L180/D110 069961
Ø 120	L20/D120 079014	L90/D120 079168	L180/D120 069978
Ø 130	L20/D130 079021	L90/D130 079175	—
Ø 140	L20/D140 079038	L90/D140 079182	—
Ø 150	L20/D150 079045	L90/D150 079199	—
Ø 160	L20/D160 079052	L90/D160 079205	—
Ø 170	L20/D170 079069	L90/D170 079212	—
Ø 180	L20/D180 079076	L90/D180 079229	—
Ø 190	L20/D190 079083	L90/D190 079236	—
Ø 200	L20/D200 079090	L90/D200 079243	—
37 LG	—		
39 & 50 LG	✓ with adapter 28L		
110, 160 & 220 LG	✓ with adapter 32L		
Protection kit for L180/D inductors - Kit de protection pour inducteurs boucle 077386 			

NEW			
	L90 BRAZ 16 Ø 1/2" / 16 mm 076907	L90 BRAZ 28 Ø 1" / 28 mm 076921	L180 BRAZ 16 Ø 1/2" / 16 mm 076914
			L180 BRAZ 28 Ø 1" / 28 mm 076938
37, 39 & 50 LG	—		
110, 160 & 220 LG	✓ with adapter 32L*		
Protection kit for BRAZ inductors - Kit de protection pour inducteurs brasage 077515 			

L180R X	
Production on request	
37, 39 & 50 LG	—
110, 160 & 220 LG	✓ with adapter 32L

ADAPTERS	
	 28L M28 Ø32 064492
	 32L M32 Ø32 064515
37 LG	—
39 & 50 LG	✓ 28L M28 Ø32
110, 160 & 220 LG	✓ 32L M32 Ø32

COMPLETE (Ø 28)		
	C20/B1 (20°) 056862	C180/B1 (90°) 056879
		C180/B2 (90°) 056886
37 LG	—	
39 & 50 LG	✓*	
110, 160 & 220 LG	—	

* = original equipment